

WARRANTY

SCM Distributors Ltd. warrants that this product will be free from defects in materials and workmanship under normal use, service and proper operation for a period of 90 days on the parts and one year on the frame from the date of the original purchase from an authorized retailer. **THIS WARRANTY SHALL NOT APPLY TO ANY PRODUCT WHICH HAS BEEN SUBJECT TO COMMERCIAL USE, ABUSE, MISUSE, ALTERATION OF ANY TYPE OR CAUSE OR TO ANY DEFECT OR DAMAGE CAUSED BY REPAIR, REPLACEMENT, SUBSTITUTION OR USE WITH PARTS OTHER THAN PARTS PROVIDED BY SCM DISTRIBUTORS LTD.** Commercial use includes use of the product in athletic clubs, health clubs, spas, gymnasiums, exercise facilities, and other public or semipublic facilities whether or not the product's use is in furtherance of a profit making enterprise, and all other use which is not for personal, family, or household purposes.

To implement this limited warranty, send a written notice stating your name, date, and place of purchase and a brief description of the defect along with your receipt to SCM Distributors Ltd. **8170 Winston Street, Burnaby, British Columbia, Canada V5A 2H5 or call us toll free 1-877-415-3425.** If the defect is covered under this limited warranty, you will be requested to return the product or part to us for free repair or replacement at our discretion. **NO ACTION FOR BREACH OF THIS LIMITED WARRANTY MAY BE COMMENCED MORE THAN ONE (1) YEAR AFTER THE DATE THE ALLEGED BREACH WAS OR SHOULD HAVE BEEN DISCOVERED. NO ACTION FOR BREACH OF ANY IMPLIED WARRANTY MAY BE COMMENCED MORE THAN ONE (1) YEAR AFTER DELIVERY OF THE PRODUCT TO THE PURCHASER. This limited warranty is not transferable. IF ANY PART OF THE PRODUCT IS NOT IN COMPLIANCE WITH THIS LIMITED WARRANTY OR ANY IMPLIED WARRANTY, THE REMEDY OF REPAIR OR REPLACEMENT IS THE EXCLUSIVE REMEDY AVAILABLE TO YOU.** In the event the purchaser makes any claim under this limited warranty or any implied warranty, the warrantor reserves the right to require the product to be returned for inspection, at the purchaser's expense, to the warrantor's premises in Burnaby, British Columbia, Canada.

SCM Distributors Ltd. It's resellers or business partners. **SHALL NOT BE LIABLE FOR THE LOSS OF USE OF ANY PRODUCT, LOSS OF TIME, INCONVENIENCE, COMMERCIAL LOSS OR ANY OTHER INDIRECT, CONSEQUENTIAL, SPECIAL OR INCIDENTAL DAMAGES DUE TO BREACH OF THE ABOVE WARRANTY OR ANY IMPLIED WARRANTY.**

This limited warranty is the only written or express warranty given by SCM Distributors, Ltd. This warranty gives you specific legal rights, and you may also have other legal rights which may vary from Province to Province or State to State. **ANY OTHER RIGHT WHICH YOU MAY HAVE, INCLUDING ANY IMPLIED WARRANTY OR MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IS LIMITED IN DURATION TO THE DURATION OF THIS LIMITED WARRANTY.**

The laws in some jurisdictions restrict the rights of manufacturers and distributors of consumer goods to disclaim or limit implied warranties and consequential and incidental damages with respect thereto. If any such law is found to be applicable, the foregoing disclaimers and limitations of and on implied warranties and consequential and incidental damages with respect thereto shall be disregarded and shall be deemed not to have been made to the extent necessary to comply with such legal restriction.

Copyright ©2010

PürAthletics® MINI 36" TRAMPOLINE

E-Z FOLD MODEL - WTE10115



WARNING

1. High-Tension springs – Always use two or more strong people to unfold or fold the PurAthletics trampoline carefully. Failure to do so may allow rails to spring back into the folded position and strike someone causing serious body injury.
2. Keep children away from the trampoline during assembly
3. Keep fingers away from the ends of the rails in the hinge area when unfolding the trampoline. The trampoline will snap into the unfolded position. Serious injury can occur if fingers are caught between the ends of the RAILS.
4. Read all instructions prior to use


PürAthletics®

Toll Free Consumer Support Call 1-877-415-3425

PurAthletics products are manufactured and Imported by
SCM Distributors Ltd, Burnaby B.C.

U.S. 1465 SLATER ROAD, FERNDALE WA 98248
CANADA 8170 Winston St. Burnaby, B.C. V5A2H5

ASSEMBLY INSTRUCTIONS

Place all parts from the box in a cleared area and position them on the floor in front of you. Place the packing material back into the box. Do not dispose of the packing materials until assembly is completed.  **If you are missing a part please call our customer service dept for assistance at 1-877-415-3425. Before returning to the retailer, please contact us.**

ASSEMBLE




fig 1.



fig 2.

1. Lay the trampoline flat on the floor and open the rails. The trampoline will look as shown in (fig 1 & 2) half moon position.
2. Unfold from half moon as shown in (fig 3) hold rails and push down to unfold the trampoline to the full flat position. Ensure you keep your hands away from the hinges. **Always use two or more strong people to unfold or fold the PurAthletics trampoline.**



fig 3.




fig 4.

3. Slide the **SAFETY PAD** over the rail frame. Make sure the holes in the safety pad fit over the 6 threaded connectors properly as shown in (fig 4)
4. Install one hole over a threaded connector. The next hole installed should be the connector on the opposite side of the trampoline. Then install the next 4 holes over the remaining connectors.
5. **The SAFETY PAD must be installed before using the trampoline.**



fig 5.

6. Remove the 6 black protective caps prior to attaching the legs. (twist and pull off)
7. Attach legs by screwing into place completely. Turn trampoline to an upright position and check to ensure that all of the legs are securely tightened and level. (fig 5)
8. Place the Trampoline in the normal use position. Make sure that the safety pad covers the elastic bands. Stand on the trampoline to ensure all six legs sit flat on the floor.
9. **DO NOT** use if any parts or missing or broken.

* **Set on level surface/use leveling kit to level trampoline before using**

DISASSEMBLE: STORAGE

1. The trampoline can be folded for easy storage. Please follow this process:

CAUTION.

- **High-Tension springs – Always use two or more strong people to unfold or fold the PurAthletics trampoline. Failure to do so may allow rails to spring back into the folded position and strike someone causing serious injury.**
- Remove the safety pad after removing legs and before folding the trampoline for storage. Failure to remove the pad will result in damage to the pad.

- A. Unscrew the legs from the trampoline. (fig 6)
- B. Remove safety pad from the frame. After the safety pad is removed, place the trampoline on the floor with the threaded connectors pointing up.




fig 6.



fig 7.



WARNING

High-Tension springs – Always use two or more strong people to unfold or fold the PurAthletics trampoline. Failure to do so may allow rails to spring back into the folded position and strike someone causing serious injury.

2. To prevent the trampoline from suddenly snapping into the folded position, push down on the four **RAILS** an even distance apart. (fig 7) Minimum two people should firmly grasp both sides of the trampoline and fold the trampoline upward. The trampoline will fold upward at the hinges.(fig 8)
3. Fold the trampoline again as shown. (fig 9)




fig 8.




fig 9.

CARE AND MAINTENANCE

Inspect the trampoline before each use. The following conditions could represent potential hazards:

1. Missing, improperly positioned, or insecurely attached frame padding.
2. Punctures, frays, tears, or holes in the bed, elastic bands, or frame padding.
3. Deterioration in the stitching or fabric of the bed or frame padding.
4. Ruptured or damaged elastic bands.
5. A bent or broken frame.
6. A sagging bed.
7. Sharp protrusions on the frame or suspension system.
8. Store the trampoline in a clean dry place.



WARNING

Before starting any exercise or conditioning program you should consult with your personal physician. This is especially important if you are over the age of 35, have never exercised before, are pregnant, or suffer from an illness.

- **Minimum two person assembly/disassembly.**
- **Intended for consumer indoor use only, not for commercial use.**

Commercial use includes use of the product in athletic clubs, health clubs, spas, gymnasiums, exercise facilities, and other public or semipublic facilities whether or not the product's use is in furtherance of a profit making enterprise, and all other use which is not for personal, family, or household purposes.

IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of serious injury, read the following safety instructions before using the PurAthletics trampoline.

1. Misuse and abuse of this trampoline is dangerous and can cause serious injuries.
2. Trampolines, being rebounding devices, propel the user to unaccustomed heights and into a variety of body movements. Avoid bouncing too high. Stay low until bounce control and repeated landing in the center of the trampoline can be accomplished. Control is more important than height.
3. Adequate overhead clearance is essential. Provide clearance for ceilings, ceiling lights, ceiling fans, wires, etc.
4. Lateral clearance is essential. Place the trampoline away from walls, structures, play areas, furniture, and other exercise equipment. Maintain a clear space on all sides of the trampoline.
5. Remove any obstructions from beneath the trampoline.
6. Use the trampoline in a well lit area. Artificial illuminations may be required for indoor or shady areas.
7. Always use the PurAthletics Trampoline on a level non slip surface. To ensure the trampoline does not slide when being used, it must be placed on an equipment mat or carpeted surface to prevent injuries. Lateral jumping motion may cause the trampoline to slide or shift on smooth flooring surfaces. **Do not place the trampoline on an elevated surface.**
The trampoline should be at floor or ground level.
8. Be sure to remove any obstructions from the area prior to use.
9. Not recommended for children age of 12 years or younger. Older children must be supervised by an adult when using the trampoline. Properly secure the trampoline when not in use. Protect it against unauthorized use.
10. Keep small children and pets away from the trampoline at all times including use and assembly /disassembly of the trampoline.
11. Always use the safety surround pad when using this product. Ensure the bed is dry.
12. The PurAthletics Trampoline is designed to accommodate one user at a time. Use by more than one person at the same time can result in serious injury.
13. Do not attempt or allow summersaults. Landing on the head or neck can cause serious injury or paralysis.
14. Step on and off the trampoline. It is a dangerous practice to jump from the trampoline to the floor or ground when dismounting. Do not jump on or off when mounting or dismounting the trampoline. Do not use the trampoline as a springboard to other objects or as a launch pad. Do not step on the safety pad when mounting, using or dismounting the trampoline.
15. Ensure the floor or ground around the trampoline is clear of all objects that may cause injury if you step on them when dismounting.
16. Do not use the PurAthletics Trampoline with socks only. Good traction is very important when mounting, using, and dismounting the PurAthletics Trampoline. Bare feet are acceptable but we recommend good footwear with rubber non-skid soles such as walking, running or cross-training shoes for safety, when trampoline is used properly.
17. Maximum weight of this trampoline is 250lbs/114kg.
18. Do not use the trampoline while under the influence of alcohol or drugs.
19. Inspect the trampoline before each use. Make sure the frame padding is correctly and securely positioned.
20. Secure the trampoline against unauthorized and unsupervised use. The owners and supervisors of the trampoline are responsible to make all users aware of safe practices specified in the use instructions.

MODÈLE : WTE10115

PURATHLETICS – MINI-TRAMPOLINE E-Z FOLD DE 91 CM (36 PO)

Directives d'assemblage

Placer toutes les pièces comprises dans la boîte sur le sol devant vous, dans un endroit dégagé. Replacer le matériel d'emballage dans la boîte. **Ne pas** jeter le matériel d'emballage avant d'avoir terminé l'assemblage. S'il vous manque une pièce, veuillez communiquer avec notre service à la clientèle, au 1-877-415-3425



Mise en garde

- 1) **Produit à ressorts très fermes : Le pliage ou le dépliage du trampoline PurAthletics doit toujours être soigneusement effectué par au moins deux personnes de bonne force physique. Si vous ne respectez pas cette directive, les tubes pourraient se replier brusquement, sous un effet de ressort, frapper quelqu'un et lui causer de graves blessures.**
- 2) **Tenir les enfants à l'écart au cours de l'assemblage du trampoline.**
- 3) **Garder les doigts à l'écart des extrémités des tubes, où se trouvent les charnières, au moment de déplier le trampoline. Le trampoline se déplie brusquement. Des graves blessures peuvent survenir si les doigts sont coincés entre les extrémités des TUBES.**

Assemblage :

- 1) Déposer le trampoline à plat sur le sol, en plaçant les tubes en position de demi-lune, tel qu'il est illustré (figures 1 et 2).
- 2) Déplier de la position de demi-lune à celle de pleine lune, tel qu'il est illustré (figure 3). Tenir les tubes et pousser vers le bas afin de placer le trampoline complètement à plat. **S'assurer de garder les mains à l'écart des charnières. Le pliage ou le dépliage du trampoline PurAthletics doit toujours être effectué par au moins deux personnes de bonne force physique.**
- 3) Enfiler le COUSSIN DE PROTECTION par-dessus la structure tubulaire. S'assurer que les trous du coussin de protection sont alignés avec les six raccords filetés, tel qu'il est illustré (figure 4).
- 4) **Aligner l'un des trous vis-à-vis un raccord fileté. Aligner le prochain trou avec le raccord se trouvant du côté opposé du trampoline.** Aligner ensuite les quatre autres trous avec les raccords restants.

- 5) **Le COUSSIN DE PROTECTION doit être installé avant d'utiliser le trampoline.**
- 6) Retirer les six embouts protecteurs noirs avant de fixer les pattes (tourner et tirer).
- 7) Visser entièrement les pattes en place. Placer le trampoline en position debout et s'assurer que toutes les pattes sont solidement fixées et au niveau (figure 5).
- 8) Placer le trampoline en position d'utilisation normale. S'assurer que le coussin de protection recouvre bien les bandes élastiques. Monter sur le trampoline afin de s'assurer que les six pattes reposent bien au sol.
- 9) **Ne pas** utiliser ce produit si toute pièce est manquante ou brisée.

Désassemblage : entreposage

- 10) Il est possible de plier le trampoline pour faciliter son rangement.
Veuillez suivre ces directives :

Mise en garde :

- **Produit à ressorts très fermes : Le pliage ou le dépliage du trampoline PurAthletics doit toujours être effectué par au moins deux personnes de bonne force physique. Si vous ne respectez pas cette directive, les tubes pourraient se replier brusquement, sous un effet de ressort, frapper quelqu'un et lui causer de graves blessures.**
 - Enlever les pattes, puis retirer le coussin de protection avant de plier le trampoline pour le ranger. Le coussin de protection sera endommagé s'il n'est pas retiré au préalable (figure 7).
- 1) Dévisser les pattes du trampoline.
 - 2) Retirer le coussin de protection de la structure. Placer ensuite le trampoline sur le sol, les raccords filetés vers le haut.



Mise en garde

Produit à ressorts très fermes : Le pliage ou le dépliage du trampoline PurAthletics doit toujours être effectué par au moins deux personnes de bonne force physique. Si vous ne respectez pas cette directive, les tubes pourraient se replier brusquement, sous un effet de ressort, frapper quelqu'un et lui causer de graves blessures.

- 11) Afin d'éviter que le trampoline ne revienne brusquement en position pliée, appuyer sur les quatre **TUBES** en les maintenant à distance égale. Au moins deux personnes doivent tenir fermement les deux côtés du trampoline et plier le trampoline vers le haut. Le trampoline se pliera vers le haut, aux charnières (figure 8).
- 12) Plier le trampoline de nouveau, tel qu'il est illustré (figure 9).

Entretien :

Inspecter le trampoline avant chaque utilisation. Les états suivants pourraient représenter des dangers potentiels :

- 1) Coussin de protection manquant, mal positionné ou mal fixé.
- 2) Toute perforation, effilochure, déchirure ou tout trou sur la surface de rebond, les bandes élastiques ou le coussin de protection.
- 3) Détérioration d'une couture ou du tissu de la surface de rebond ou du coussin protecteur.
- 4) Bande élastique rompue ou endommagée.
- 5) Structure pliée ou brisée.
- 6) Surface de rebond affaissée.
- 7) Saillies pointues sur la structure ou le système de suspension.
- 8) Ranger le trampoline dans un endroit propre et sec.

IMPORTANTES DIRECTIVES EN MATIÈRE DE SÉCURITÉ

Mise en garde : Afin de réduire les risques de blessures graves, veuillez lire ces directives de sécurité avant d'utiliser le trampoline PurAthletics.

- 1) La mauvaise utilisation et l'abus de ce trampoline est dangereux et peut causer de graves blessures.
- 2) Servant à rebondir, le trampoline propulse l'utilisateur à des hauteurs inhabituelles et selon divers mouvements corporels. Éviter de rebondir trop haut. Faire de petits bonds jusqu'à ce que vous maîtrisiez bien les rebonds et atterrissez au centre du trampoline. Le contrôle du rebond est plus important que sa hauteur.
- 3) Il est essentiel de prévoir un dégagement libre adéquat au-dessus de la tête. Prévoir un dégagement suffisant entre les plafonds, luminaires, ventilateurs de plafond, fils, etc.
- 4) Il est essentiel de prévoir un dégagement latéral suffisant. Placer le trampoline à l'écart des murs, structures, aires de jeux, meubles et tout autre équipement d'exercice. Maintenir un espace libre sur tous les côtés du trampoline.
- 5) Retirer tout obstacle se trouvant sous le trampoline.
- 6) Utiliser le trampoline dans un endroit bien éclairé. Il peut être nécessaire d'utiliser un éclairage artificiel dans les emplacements intérieurs ou ombragés.
- 7) Utiliser toujours le trampoline PurAthletics sur une surface antidérapante et au niveau. Afin de s'assurer que le trampoline ne glisse pas lors de l'utilisation, il doit être placé sur un tapis d'équipement ou une surface recouverte de tapis afin de prévenir les blessures. Tout saut latéral peut faire glisser ou bouger le trampoline sur une surface lisse. **Ne pas placer le trampoline sur une surface surélevée. Le trampoline doit être placé au niveau du sol.**
- 8) S'assurer de retirer tout obstacle de la zone à proximité avant l'utilisation.
- 9) Non recommandé pour les enfants de 12 ans et moins. Les enfants plus vieux doivent être supervisés par un adulte au moment d'utiliser le trampoline. Ranger le trampoline de façon sécuritaire entre les utilisations; de façon à éviter toute utilisation non autorisée.

- 10) Tenir les jeunes enfants et les animaux domestiques à l'écart du trampoline en tout temps, y compris durant l'utilisation, l'assemblage et le désassemblage du trampoline.
- 11) Toujours utiliser le coussin de protection de sécurité au moment d'utiliser ce produit. S'assurer que la surface de rebond est sèche avant toute utilisation.
- 12) Le trampoline PurAthletics est conçu pour accueillir un seul utilisateur à la fois. S'il est utilisé par plus d'une personne à la fois, cela pourrait entraîner de graves blessures.
- 13) Ne pas tenter ni permettre d'effectuer de sauts périlleux. Un atterrissage sur la tête ou le cou peut causer de graves blessures ou même la paralysie.
- 14) Monter et descendre du trampoline en marchant. Il est dangereux de sauter du trampoline au sol pour en descendre. Ne pas monter ni descendre du trampoline en sautant. Ne pas utiliser le trampoline en guise de tremplin pour atteindre d'autres objets ni en guise de plateforme de lancement. Ne pas marcher sur le coussin de protection au moment de monter, d'utiliser le trampoline ou d'en descendre.
- 15) S'assurer que le sol entourant le trampoline est libre de tout objet pouvant causer des blessures si l'on marche dessus en descendant du trampoline.
- 16) Ne pas utiliser le trampoline PurAthletics en ne portant que des chaussettes. Il est très important d'avoir une bonne traction au moment de monter, d'utiliser le trampoline PurAthletics et d'en descendre. Lorsque le trampoline est utilisé de façon appropriée, il est acceptable de l'utiliser pieds nus, mais nous recommandons d'utiliser de bonnes chaussures à semelles de caoutchouc antidérapantes, telles que des chaussures de marche, d'entraînement ou de course pour plus de sécurité.
- 17) Poids maximal de tout utilisateur du trampoline : 114 kg (250 lb).
- 18) Ne pas utiliser le trampoline si vous avez les facultés affaiblies par l'alcool ou la drogue.
- 19) Inspecter le trampoline avant chaque utilisation. S'assurer que le coussin de protection est positionné correctement et de façon sécuritaire.

20)

- 1) **MISE EN GARDE : Il est préférable de consulter votre médecin de famille avant d'entreprendre tout programme d'exercice ou de conditionnement physique. Cela est particulièrement important si vous êtes âgé de plus de 35 ans, n'avez jamais fait d'exercice auparavant, êtes enceinte ou souffrez d'une maladie.**
- 2) **Au moins deux personnes sont requises pour effectuer l'assemblage et le désassemblage.**
- 3) **Conçu uniquement pour une utilisation personnelle à l'intérieur. Ne pas utiliser à des fins commerciales.**

L'utilisation commerciale comprend l'usage du produit dans tout club d'athlétisme, centre de culture physique, spa, gymnase, salle d'exercice ou toute autre installation publique ou parapublique, que l'utilisation du produit soit liée ou non à une entreprise à but lucratif, ainsi que tout autre usage non lié à des fins personnelles, familiales ou domestiques.

- 21) Ranger le trampoline afin d'éviter toute utilisation non autorisée et non supervisée. Les propriétaires et superviseurs du trampoline sont responsables de veiller à ce que tout utilisateur connaisse les pratiques sécuritaires précisées dans les directives d'utilisation.